

1. Be sure that the cable coming from the modem is plugged in to the WAN port or Internet port on the back of the router, and your computer is plugged into any of the ports labeled 1 through 4.

※NOTE: These Instructions are only for routers that are new with no setup on them or currently owned routers that have been set to factory default.※


2. Open up your internet browser.
3. In the address bar, type 192.168.2.1 and hit enter.



4. The Belkin Main Menu will appear. On the left side click on Connection Type.



5. It will come up asking for the password. Unless you changed the password. Leave the password field blank and hit submit.
6. The screen will appear to the WAN Connection Type. Put a dot next to PPPOE and then hit the next button.



7. Next for the WAN Connection Type, the PPPoE screen will appear. Enter the Username and password provided to you by the internet provider. Also adjust the MTU size to 1454. Then select apply changes. The router will save the settings and is now configured for PPPOE